



Operation & Safety Instructions

CHAFING DISH



INSTRUCTIONS

Remove lid and food container and fill bottom basin with 2 litres for round dish or 8 Litres for rectangle dishes, of boiling water for a maximum of 2.5 hours heating. Before replacing container into water basin, remove lid from fuel burners and place burner and holder into space provided in the frame under basin.

Ignite fuel and carefully place food containers into water basin.
To extinguish flame replace lid over fuel carefully. Fuel can be re-ignited if required.

Please note: Chafing dishes are designed to maintain food temperature only. Ensure foods are placed in chafing dishes at the required service temperatures.

Please take extreme care when emptying the water basin and with fuel flames.

Your kit contains:	
1 x Frame	
1 x Lid	
1x Inner tray & insert tray/s (2x if half tray)	
2 x Fuel Cells & 2 cell pots/covers	